

Inkjet	_____	2
Laser	_____	19
Scanner	_____	20
SIDM	_____	21

Model name or Driver Name	Windows10(1803) Supported by		Windows10(1803) Supported by	
	o: EPSON driver w: Windows Update driver x: Not supported	EPSON driver version	o: Support by the latest version -: Not apply	Support Version
	WF-C5290 Series	o	2.6	-
WF-C5290 Series	o	2.6	-	-
WF-C5710 Series	o	2.6	o	6.4.1.0
WF-C5710 Series	o	2.6	o	
WF-C5790 Series	o	2.6	o	6.4.0.0
WF-C5790 Series	o	2.6	o	
XP-15000 Series	o	2.6	-	-
XP-15000 Series	o	2.6	-	-
XP-6000 Series	o	2.6	o	6.4.0.0
XP-6000 Series	o	2.6	o	
XP-8500 Series	o	2.6	o	6.4.9.0
XP-8500 Series	o	2.6	o	
L4150 Series	o	2.62	o	6.4.0.0
L4150 Series	o	2.62	o	
L4160 Series	o	2.62	o	6.4.0.0
L4160 Series	o	2.62	o	
L6170 Series	o	2.6	o	6.4.9.0
L6170 Series	o	2.6	o	
L6160 Series	o	2.6	o	6.4.0.0
L6160 Series	o	2.6	o	
L6190 Series	o	2.6	o	6.4.9.0
L6190 Series	o	2.6	o	
WF-7210 Series	o	2.6	-	-
WF-7210 Series	o	2.6	-	-
WF-7710 Series	o	2.6	o	6.4.0.0
WF-7710 Series	o	2.6	o	
WF-7720 Series	o	2.6	o	6.4.0.0
WF-7720 Series	o	2.6	o	
WF-C20590 Series	o	2.63	o	6.4.3.0
WF-C20590 Series	o	2.63	o	
WF-C17590 Series	o	2.63	o	6.4.3.0
WF-C17590 Series	o	2.63	o	
XP-240 Series	o	2.5	o	Ver.6.210
XP-240 Series	o	2.5	o	Ver.6.210
XP-340 Series	o	2.5	o	Ver.6.210
XP-340 Series	o	2.5	o	Ver.6.210
XP-440 Series	o	2.5	o	Ver.6.210
XP-440 Series	o	2.5	o	Ver.6.210
XP-440 Series	o	2.5	o	Ver.6.210
XP-243 245 247 Series	o	2.5	o	Ver.6.210
XP-342 343 345 Series	o	2.5	o	Ver.6.210
XP-442 445 Series	o	2.5	o	Ver.6.210
XP-900 Series	o	2.5	o	Ver.6.210
XP-640 Series	o	2.5	o	Ver.6.210
XP-640 Series	o	2.5	o	Ver.6.210
XP-540 Series	o	2.5	o	Ver.6.210
L1455 Series	o	2.5	o	Ver.6.220
WF-C869R Series	o	2.61	o	Ver.6.220
WF-C869R Series	o	2.61	o	Ver.6.220
WF-4740 Series	o	2.62	o	Ver.6.220
WF-4740 Series	o	2.62	o	Ver.6.220

WF-4730 Series	0	2.62	0	Ver.6.220
WF-4730 Series	0	2.62	0	Ver.6.220
WF-4730 Series	0	2.62	0	Ver.6.220
WF-4730 Series	0	2.62	0	Ver.6.220
WF-4720 Series	0	2.62	0	Ver.6.220
WF-4720 Series	0		0	Ver.6.220
WF-3720 Series	0	2.62	0	Ver.6.220
WF-3720 Series	0		0	Ver.6.220
L395 Series	0	2.5	0	Ver.6.210
L495 Series	0	2.5	0	Ver.6.210
L605 Series	0	2.51	0	Ver.6.220
L485 Series	0	2.5	0	Ver.6.210
L486 Series	0		0	Ver.6.210
L385 Series	0	2.5	0	Ver.6.210
L386 Series	0		0	Ver.6.210
L380 Series	0		0	Ver.6.210
L380 Series	0	2.5	0	Ver.6.210
L382 Series	0		0	Ver.6.210
L380 Series	0		0	Ver.6.210
PM-520 Series		2.6		
PM-520 Series		2.6		
WF-2750 Series	0	2.41	0	5.2.2.1
WF-2750 Series	0		0	
WF-2760 Series	0	2.41	0	
WF-2760 Series	0		0	
XP-220 Series	0	2.51	0	Ver.4.021
XP-230 Series			0	Ver.4.021
XP-330 Series	0	2.52	0	Ver.4.021
XP-430 Series			0	Ver.4.021
XP-430 Series			0	Ver.4.021
XP-235 Series			0	Ver.4.021
XP-332 335 Series	0	2.53	0	Ver.4.021
XP-432 435 Series			0	Ver.4.021
XP-830 Series			0	Ver.4.020
XP-830 Series			0	Ver.4.020
XP-630 Series	0	2.52	0	Ver.4.020
XP-630 Series			0	Ver.4.020
XP-530 Series			0	Ver.4.020
XP-530 Series			0	Ver.4.020
L655 Series			0	Ver.4.020
L655 Series			0	Ver.4.020
L575 Series			0	Ver.4.020
L475 Series			0	Ver.4.020
L375 Series			0	Ver.4.020
L805 Series	0	2.50	-	-
L805 Series	0	2.50	-	-
PM-400 Series			-	-
PM-400 Series	0	2.50	-	-
WF-6530 Series			0	Ver.5.220
WF-6590 Series			0	Ver.5.220
WF-6590 Series	0	2.42	0	Ver.5.220
WF-6090 Series			-	-
WF-6090 Series			-	-
WF-2650 Series			0	5.2.2.4
WF-2650 Series	0	2.41	0	
WF-2660 Series			0	
WF-2660 Series			0	
WF-R4640 Series			0	Ver.5.222
WF-R5690 Series			0	Ver.5.222
WF-R5690 Series	0	2.40	0	Ver.5.222

WF-R5190 Series			-	-
WF-R5190 Series			-	-
WF-M5690 Series	o	2.44	o	Ver.5.221
WF-M5190 Series			-	-
WF-R8590 Series	o	2.47	o	Ver.5.222
WF-R8590 Series			o	Ver.5.222
XP-860 Series			o	Ver.4.011
XP-860 Series	o	2.22	o	Ver.4.011
XP-760 Series			o	Ver.4.011
XP-820 Series			o	Ver.4.011
XP-820 Series			o	Ver.4.011
XP-620 Series	o	2.22	o	Ver.4.011
XP-620 Series			o	Ver.4.011
XP-720 Series			o	Ver.4.011
XP-520 Series	o	2.20	o	Ver.4.011
XP-520 Series			o	Ver.4.011
L850 Series			o	Ver.4.010
L850 Series	o	2.21	o	Ver.4.010
L810 Series			-	-
L810 Series			-	-
WF-2630 Series	o	2.40	o	5.2.2.4
WF-2630 Series			o	
XP-220 Series			o	Ver.4.020
XP-320 Series			o	Ver.4.020
XP-320 Series	o	2.21	o	Ver.4.020
XP-420 Series			o	Ver.4.020
XP-420 Series			o	Ver.4.020
XP-225 Series			o	Ver.4.020
XP-322 323 325 Series	o	2.21	o	Ver.4.020
XP-422 423 425 Series			o	Ver.4.020
L565 Series			o	Ver.4.012
L565 Series	o	2.43	o	Ver.4.012
L566 Series			o	Ver.4.012
L362 Series			o	Ver.4.012
L360 Series			o	Ver.4.012
L220 Series			o	Ver.4.012
L220 Series			o	Ver.4.012
L222 Series			o	Ver.4.012
L365 Series			o	Ver.4.012
L365 Series	o	2.22	o	Ver.4.012
L366 Series			o	Ver.4.012
L310 Series			-	-
L310 Series			-	-
L312 Series			-	-
L130 Series			-	-
L132 Series			-	-
L455 Series			o	Ver.4.012
L455 Series	o	2.22	o	Ver.4.012
L456 Series			o	Ver.4.012
WF-100 Series			-	-
WF-100 Series	o	2.42	-	-
WF-100 Series			-	-
L1300 Series	o	2.12	-	-
L1300 Series			-	-
L1800 Series	o	2.12	-	-
L1800 Series			-	-
L120 Series	o	2.11	-	-
L120 Series			-	-
XP-412 413 415 Series			o	
XP-312 313 315 Series	o	2.11	o	Ver.3.702

XP-215 217 Series	0	7.11	0	Ver.3.792
XP-212 213 Series			0	
XP-410 Series			0	
XP-310 Series	0	7.16	0	
XP-211 214 216 Series			0	
XP-950 Series	0	7.13	0	Ver.4.010
XP-510 Series	0	7.10	0	Ver.4.010
XP-810 Series			0	
XP-710 Series	0	7.10	0	Ver.4.010
XP-610 Series			0	
WF-8510 Series			0	
WF-8590 Series	0	2.46	0	
WF-8010 Series			0	
WF-8090 Series			0	
WF-5620 Series			0	
WF-4630 Series			0	
WF-4640 Series	0	2.46	0	
WF-5690 Series			0	
WF-5110 Series			0	
WF-5190 Series			0	
WF-3640 Series	0	2.32	0	5.2.2.3
WF-3620 Series			0	
WF-7620 Series			0	5.2.2.3
WF-7610 Series	0	2.32	0	
WF-7110 Series			-	-
WF-3540 Series			0	
WF-3540 Series			0	
WF-3540 Series			0	
WF-3530 Series			0	
WF-3530 Series			0	
WF-3530 Series	0	1.52	0	Ver.3.790
WF-3530 Series			0	
WF-3520 Series			0	
WF-3520 Series			0	
WF-3520 Series			0	
WF-3010 Series			0	
WF-3010 Series			0	
WF-3010 Series			0	
XP-850 Series			0	Ver.3.790
XP-850 Series	0	7.01	0	Ver.3.796
XP-750 Series			0	Ver.3.796
XP-800 Series			0	Ver.3.790
XP-800 Series			0	Ver.3.790
XP-800 Series			0	Ver.3.795
XP-800 Series			0	Ver.3.795
XP-700 Series			0	Ver.3.790
XP-700 Series	0	7.02	0	Ver.3.790
XP-700 Series			0	Ver.3.795
XP-700 Series			0	Ver.3.795
XP-600 Series			0	Ver.3.790
XP-600 Series			0	Ver.3.792
XP-600 Series			0	Ver.3.792
WF-M1560 Series			0	Ver.3.790
WF-M1560 Series	0	1.51	0	Ver.3.791
WF-M1560 Series			0	Ver.3.791
M105 Series			0	
M105 Series			0	
M105 Series			0	
M205 Series			0	Ver.3.790
M205 Series	0	1.55	0	Ver.3.793

M200 Series			0	Ver.3.793
M200 Series			0	Ver.3.793
M100 Series			0	
M100 Series			0	
WF-2540 Series			0	Ver.3.790
WF-2540 Series			0	Ver.3.792
WF-2540 Series			0	Ver.3.792
WF-2530 Series			0	Ver.3.790
WF-2530 Series			0	Ver.3.790
WF-2530 Series			0	Ver.3.792
WF-2530 Series	0	1.54	0	Ver.3.792
WF-2520 Series			0	Ver.3.790
WF-2520 Series			0	Ver.3.792
WF-2520 Series			0	Ver.3.792
WF-2510 Series			0	Ver.3.790
WF-2510 Series			0	Ver.3.790
WF-2510 Series			0	Ver.3.792
WF-2510 Series			0	Ver.3.792
WF-2010 Series	0	1.53	-	
WF-2010 Series			-	
XP-201 204 208 Series			0	
XP-200 Series			0	
XP-200 Series	0	7.00	0	Ver.3.793
XP-100 Series			0	
XP-100 Series			0	Ver.3.793
PX-435A Series	0	7.03	0	Ver.3.793
PX-405A Series			0	Ver.3.793
XP-400 Series			0	
XP-400 Series			0	
XP-400 Series			0	Ver.3.793
XP-400 Series	0	7.00	0	Ver.3.793
XP-300 Series			0	
XP-300 Series			0	Ver.3.793
ME-303 Series			0	Ver.3.793
XP-205/207 Series			0	Ver.3.793
XP-202/203/206 Series			0	Ver.3.793
XP-202/203/206 Series			0	Ver.3.793
XP-102/103 Series	0	7.00	0	Ver.3.793
XP-102/103 Series			0	Ver.3.793
XP-30/33 Series			0	
XP-30/33 Series			0	
XP-402/403/405/406 Series			0	Ver.3.793
XP-402/403/405/406 Series			0	Ver.3.793
XP-302/303/305/306 Series	0	7.00	0	Ver.3.793
XP-302/303/305/306 Series			0	Ver.3.793
L350 Series			0	Ver.3.790
L350 Series			0	Ver.3.793
L300 Series			0	
L300 Series			0	
L210 Series	0	1.51	0	Ver.3.790
L210 Series			0	Ver.3.793
L210 Series			0	Ver.3.793
L110 Series			0	
L110 Series			0	
L110 Series			0	
L355 series			0	Ver.3.791
L355 series	0	1.54	0	Ver.3.791
L355 series			0	Ver.3.793
L550 Series			0	Ver.3.790
L550 Series	0	1.51	0	Ver.3.792

L555 Series	0	1.31	0	Ver.3.790
L555 Series			0	Ver.3.792
ME-100 Series	0	7.02	0	Ver.3.792
ME-10 Series			0	
Epson ME 340			0	Ver.3.784
Epson Stylus SX230 Series	0	6.93	0	Ver.3.784
Epson Stylus SX235W Series			0	Ver.3.783
Epson Stylus TX235 Series	0	6.93	0	Ver.3.784
Epson ME OFFICE 530 Series			0	Ver.3.784
Epson Stylus NX230 Series			0	
Epson Stylus TX230 Series	0	6.93	0	
Epson Stylus NX230 / TX230			0	Ver.3.783
WP-M4525			0	Ver.3.792
WP-M4521			0	Ver.3.792
WP-M4595	0	1.34	0	Ver.3.792
WP-M4015			0	
WP-M4011			0	
WP-M4095			0	
WP-4521 Series			0	Ver.3.783
WP-4511 Series			0	Ver.3.783
WP-4011 Series			0	
WP-4091 Series			0	
WP-4531 Series	0	1.31	0	
WP-4530 Series			0	
WP-4540 Series			0	Ver.3.783
WP-4590 Series			0	Ver.3.782
WP-4090 Series			0	
WP-4525 Series			0	Ver.3.783
WP-4515 Series			0	Ver.3.783
WP-4535 Series			0	
WP-4545 Series	0	1.31	0	Ver.3.783
WP-4595 Series			0	Ver.3.782
WP-4015 Series			0	
WP-4025 Series			0	
WP-4095 Series			0	
WP-4532 Series			0	
WP-4592 Series			0	
WP-4022 Series			0	
WP-4092 Series			0	
WP-4530 Series			0	
WP-4540 Series			0	
WP-4590 Series	0	1.32	0	
WorkForce Pro 70			0	
WP-4090 Series			0	
WP-4520 Series			0	
WP-4533 Series			0	
WP-4010 Series			0	
WP-4023 Series			0	
PictureMate PM245	0	6.92	0	
PX-1600F	0	1.59	0	Ver.3.784
WF-7511 Series			0	Ver.3.784
WF-7521 Series			0	Ver.3.784
WF-7011 Series			0	
WF-7018 Series	0	1.22	0	
WF-7510 Series			0	Ver.3.784
WF-7520 Series			0	Ver.3.784
WF-7010 Series			0	
WF-7515 Series			0	Ver.3.784
WF-7525 Series	0	1.22	0	Ver.3.784
WF-7015 Series			0	

WF-7510 Series			0	
WF-7520 Series	o	1.23	0	
WF-7010 Series			0	
Epson ME OFFICE 620F	o	6.72	0	
WorkForce 320, Epson Stylus Office TX320F	o	6.72	0	
Epson Stylus Office BX305, TX320 WorkForce320	o	6.72	0	
Epson Stylus Photo PX820FWD, TX820 Artisan830	o	6.72	0	
Epson Stylus Photo PX820FWD, TX820 Artisan830	o	6.72	0	
L100, L200	o	6.71	0	
L100, L200	o	6.75	0	
K300	o	1.12	0	
K300, K301	o	1.12	0	
K300, K301	o	1.12	0	
K100, K200	o	1.02	0	
K100, K200	o	1.02	0	
K100	o	1.02	0	
PX-K100	o	1.01	-	
Epson Stylus NX620, Epson Stylus TX560WD, WorkForce 630, Epson Stylus Office TX620FWD	o	6.75	0	
Epson ME OFFICE 900WD, Epson ME OFFICE 960FWD	o	6.75	0	
Epson Stylus SX525WD, Epson Stylus Office BX525WD, WorkForce 620, Epson Stylus Office BX620FWD, WorkForce 630	o	6.75	0	
L800	o	6.71	-	
L800	o	6.72	-	
Epson Stylus Photo PX660	o	6.72	0	
Epson Stylus NX420, Epson Stylus TX420W	o	6.72	0	
Epson ME OFFICE 560W	o	6.72	0	
Epson Stylus SX420W, TX420 NX420	o	6.72	0	
Epson Stylus SX420W, TX420 NX420	o	6.72	0	
Epson ME OFFICE 82WD	o	6.72	-	
Epson Stylus Office B42WD, WorkForce 60	o	6.72	-	
Epson Stylus TX220	o	6.72	0	
Epson ME OFFICE 520	o	6.72	0	

Epson Stylus N10 N11, Epson Stylus T22, Epson Stylus T25, Epson Stylus NX125 NX127, Epson Stylus TX120, Epson Stylus TX125	o	6.73	o	
Epson ME 32, Epson ME 33, Epson ME 320, Epson ME 330	o	6.74	o	
Epson Stylus S22, T12 T22 N11, T13 T22E, Epson Stylus SX125, TX120 NX120, Epson Stylus TX121	o	6.73	o	
Epson Stylus S22, T12 T22 N11, T13 T22E, Epson Stylus SX125, TX120 NX120, Epson Stylus TX121	o	6.73	o	
Epson ME 35, Epson ME 350	o	6.75	o	
Stylus S21, Stylus T21, Stylus T27	o	6.63		
Stylus T21, Stylus T24	o	6.63		
Stylus S21, Stylus T21, Stylus T27	o	6.63		
Stylus Photo P50, Stylus Photo T50, Stylus Photo T59, Stylus Photo T60	o	6.62		
Artisan 50, Stylus Photo T50	o	6.62		
Stylus Photo P50, Stylus Photo T50, Stylus Photo T59, Stylus Photo T60	o	6.62		
Stylus Photo R330	o	6.63		
PX-1001	o	6.63		
Epson Stylus Office B1100, Epson Stylus Office T1100	o	6.62		
ME OFFICE 1100	o	6.62		
Stylus NX110, Stylus TX110, Stylus TX115	o	6.62		Ver.3.731
Stylus SX110, Stylus TX110, Stylus TX111, Stylus TX117, Stylus TX119	o	6.62		
Stylus SX110, Stylus TX110, Stylus TX111, Stylus TX117, Stylus TX119	o	6.62		
Stylus Office BX310FN, Stylus Office TX510FN	o	6.62		Ver.3.760
WorkForce 310, Stylus Office TX515FN	o	6.62		
ME OFFICE 650FN	o	6.62		
Stylus Office BX310FN, Stylus Office TX510FN	o	6.62		
PictureMate PM 235, PictureMate PM 300, PictureMate PM 310	o	6.62		

PictureMate PM 235, PictureMate PM 300, PictureMate PM 310	o	6.62		
PictureMate PM 225, PictureMate PM 300	o	6.62		
PictureMate PM 235, PictureMate PM 300, PictureMate PM 310	o	6.62		
Stylus Photo PX810FW, Stylus Photo TX810FW, Stylus Photo PX710W, Stylus Photo TX710W	o	6.62		
Stylus SX510W, Stylus TX550W	o	6.63		Ver.3.760
Stylus NX510, Stylus TX550W	o	6.63		
Stylus SX510W, Stylus TX550W	o	6.63		
Epson Stylus SX610FW, Epson Stylus Office BX610FW, Epson Stylus Office TX610FW	o	6.63		Ver.3.760
Epson Stylus SX610FW, Epson Stylus Office BX610FW, Epson Stylus Office TX610FW	o	6.63		
WorkForce 610	o	6.63		
Stylus Photo PX650, Stylus Photo TX650, Stylus Photo TX659	o	6.62		Ver.3.760
Stylus Photo PX650, Stylus Photo TX650, Stylus Photo TX659	o	6.62		
Stylus SX210, Stylus TX210	o	6.63		Ver.3.760
Stylus NX210, Stylus TX210	o	6.63		
ME OFFICE 510	o	6.63		
Stylus SX210, Stylus TX210	o	6.63		
B-318N/518DN	o	6.72		
B-310N/510DN	o	6.72		
B-310N/510DN	o	6.72		
ME OFFICE 70	o	6.65		
Stylus Office T30	o	6.64		
Stylus Office T30	o	6.64		
Stylus Office T30	o	6.64		
WorkForce 30, STYLUS OFFICE T30, STYLUS OFFICE T33	o	6.64		
ME OFFICE 70	o	6.65		
STYLUS OFFICE B30, Stylus Office T30	o	6.64		
STYLUS OFFICE B30, Stylus Office T30	o	6.64		
STYLUS TX200	o	6.64		
STYLUS TX200	o	6.64		
STYLUS TX200	o	6.64		
STYLUS TX200	o	6.64		
STYLUS TX400	o	6.64		
STYLUS TX400	o	6.64		

STYLUS NX200, STYLUS NX400, STYLUS TX200, STYLUS TX400	o	6.64		Ver.3.490
STYLUS SX200, STYLUS SX400, STYLUS TX200, STYLUS TX400	o	6.64		
STYLUS SX200, STYLUS SX400, STYLUS TX200, STYLUS TX400	o	6.64		
ME 300	o	6.64		
STYLUS TX100	o	6.63		
STYLUS TX101	o	6.63		
STYLUS TX100	o	6.63		
STYLUS TX100	o	6.63		
STYLUS NX100, STYLUS TX100, STYLUS TX105	o	6.62		
ME 300	o	6.64		
STYLUS SX100, STYLUS TX100, STYLUS TX101, STYLUS TX106, STYLUS TX109	o	6.63		
STYLUS SX100, STYLUS TX100, STYLUS TX101, STYLUS TX106, STYLUS TX109	o	6.63		
PictureMate PM215	o	6.62		
PictureMate PM215	o	6.62		
PictureMate PM215	o	6.62		
PictureMate PM215	o	6.62		
STYLUS T11	o	6.64		
STYLUS T10	o	6.64		
STYLUS T20	o	6.64		
STYLUS T20E	o	6.64		
STYLUS T20	o	6.64		
STYLUS T20	o	6.64		
STYLUS T20, STYLUS T23	o	6.63		
STYLUS S20, STYLUS T10, STYLUS T11, STYLUS T20, STYLUS T20E, STYLUS T26	o	6.64		
STYLUS S20, STYLUS T10, STYLUS T11, STYLUS T20, STYLUS T20E, STYLUS T26	o	6.64		
STYLUS OFFICE TX600FW, WorkForce 600	o	6.66		
ME OFFICE 700FW	o	6.68		
STYLUS OFFICE BX600FW, STYLUS OFFICE TX600FW, STYLUS SX600FW	o	6.67		Ver.3.490

STYLUS OFFICE BX600FW, STYLUS OFFICE TX600FW, STYLUS SX600FW	o	6.67		
STYLUS PHOTO TX800FW	o	6.64		
STYLUS PHOTO PX700W, STYLUS PHOTO PX800FW, STYLUS PHOTO TX700W, STYLUS PHOTO TX800FW	o	6.64		
STYLUS PHOTO PX700W, STYLUS PHOTO PX800FW, STYLUS PHOTO TX700W, STYLUS PHOTO TX800FW	o	6.64		
EP-301, PM-A840S	o	6.64		Ver.3.490
STYLUS OFFICE T40W, WorkForce 40	o	6.66		
ME OFFICE 80W	o	6.68		
STYLUS OFFICE T40W	o	6.67		
STYLUS OFFICE T40W	o	6.67		
STYLUS OFFICE T40W	o	6.67		
ME OFFICE 80W	o	6.68		
PX-201	o	6.66		
STYLUS OFFICE B40W, STYLUS OFFICE T40W	o	6.67		
STYLUS OFFICE B40W, STYLUS OFFICE T40W	o	6.67		
STYLUS NX300, STYLUS OFFICE TX300F	o	6.63		Ver.3.490
ME OFFICE 600F	o	6.64		
STYLUS OFFICE TX300F	o	6.64		
STYLUS OFFICE TX300F	o	6.64		
STYLUS OFFICE TX300F	o	6.64		
STYLUS OFFICE BX300F, STYLUS OFFICE TX300F	o	6.64		
ME OFFICE 600F	o	6.64		
STYLUS OFFICE BX300F, STYLUS OFFICE TX300F	o	6.64		
STYLUS OFFICE BX300F, STYLUS OFFICE TX300F	o	6.64		
WorkForce 500	o	6.62		Ver.3.490
PX-5600	o	6.61		
STYLUS PHOTO R2880	o	6.61		
EPSON Stylus Photo R2880	o	6.61		
EPSON Stylus Photo R2880	o	6.61		
STYLUS PHOTO R2880	o	6.61		
STYLUS PHOTO R1900	o	6.62		
Stylus CX4400, Stylus CX5600	o	6.55		Rev.3.0ze
Stylus CX5500	o	6.56		
Stylus CX4300	o	6.56		

Stylus CX4300, Stylus CX5500, Stylus DX4400	o	6.56		
Stylus Photo RX680	o	6.55	Ver.3.240	
Stylus Photo RX690	o	6.55		
Stylus Photo RX690	o	6.55		
Stylus Photo RX685	o	6.55		
Stylus Photo RX685	o	6.55		
Stylus Photo RX690	o	6.55		
Stylus Photo RX685, Stylus Photo RX690	o	6.55		
PX-A640, PX-A740	o	6.55	Ver.3.200	
Stylus CX7300, Stylus CX7400, Stylus CX8300, Stylus CX8400	o	6.53		
Stylus CX8300	o	6.53		
Stylus CX7300, Stylus CX8300	o	6.53		
Stylus CX7300, Stylus CX8300, Stylus DX7400, Stylus DX8400	o	6.53		
STYLUS PHOTO RX595, Stylus Photo RX610	o	6.55	Ver.3.240	
Stylus Photo RX610	o	6.55		
Stylus Photo RX585	o	6.55		
Stylus Photo RX585, Stylus Photo RX610	o	6.55		
PictureMate PM 260, PictureMate PM 290	o	6.53		
PictureMate PM 270	o	6.53		
PictureMate PM 260, PictureMate PM 290	o	6.53		
PictureMate PM 260, PictureMate PM 270, PictureMate PM 290	o	6.53		
STYLUS PHOTO R280, STYLUS PHOTO R290	o	6.54		
STYLUS PHOTO R290	o	6.54		
STYLUS PHOTO R290	o	6.54		
STYLUS PHOTO R290	o	6.54		
STYLUS PHOTO R290	o	6.54		
STYLUS PHOTO R290	o	6.54		
STYLUS PHOTO R285	o	6.54		
STYLUS PHOTO R285	o	6.54		
STYLUS PHOTO R290	o	6.54		
STYLUS PHOTO R285, STYLUS PHOTO R290	o	6.54		
PM-A840, PM-G860	o	6.57		Ver.3.24
PM-A940, PM-T960	o	6.57		Ver.3.24
B-300, B-308, B-500DN, B- 508DN	o	6.58		
B-508DN	o	6.58		
B-300, B-500DN	o	6.58		
B-308	o	6.58		

B-300, B-308, B-500DN, B-508DN	o	6.58		
B-300, B-308, B-500DN, B-508DN	o	6.58		
	o	6.55		
Stylus CX9300F, Stylus CX9400Fax	o	6.53		Ver.3.241
Stylus CX9300F	o	6.53		
Stylus CX9300F, Stylus DX9400F	o	6.53		
PictureMate PM200	o	6.53		
PictureMate PM210	o	6.52		
Stylus C59	o	6.52		
ME 2, Stylus C58, Stylus C59	o	6.52		
Stylus Photo 1390	o	6.51		
Stylus Photo R380	o	6.53		
Stylus Photo R390	o	6.52		
Stylus Photo R360	o	6.52		
Stylus Photo R360, Stylus Photo R390	o	6.52		
	o	6.53		Rev.2.6m
Stylus CX4900, Stylus CX5000, Stylus CX5900, Stylus CX6000	o	6.53		
Stylus CX4900	o	6.52		
Stylus CX5900	o	6.52		
Stylus DX5000, Stylus DX6000	o	6.52		
Stylus CX4900, Stylus CX5900, Stylus DX5000, Stylus DX6000	o	6.52		
STYLUS CX6900F, STYLUS CX7000F	o	6.53		Rev.2.9m
STYLUS CX6900F, STYLUS DX7000F	o	6.52		
	o	6.53		
PictureMate PM240, PictureMate PM280	o	6.53		
PictureMate PM250	o	6.52		
PictureMate PM240	o	6.52		
PictureMate PM280	o	6.52		
PictureMate PM240, PictureMate PM250, PictureMate PM280	o	6.52		
	o	6.53		Rev.2.9r
Stylus CX3900, Stylus CX4000	o	6.53		
Stylus CX3900	o	6.52		
Stylus CX3900	o	6.52		
Stylus CX3900, Stylus DX4000	o	6.52		
Stylus Photo R260, Stylus Photo R270	o	6.53		
Stylus Photo R270	o	6.52		
Stylus Photo R265	o	6.52		
Stylus Photo R265	o	6.52		

Stylus Photo R270	o	6.52		
Stylus Photo R265, Stylus Photo R270	o	6.52		
Stylus Photo RX580, Stylus Photo RX590	o	6.53		Rev.3.0u
Stylus Photo RX590	o	6.52		
Stylus Photo RX560	o	6.52		
Stylus Photo RX560	o	6.52		
Stylus Photo RX590	o	6.52		
Stylus Photo RX560, Stylus Photo RX590	o	6.52		
PM-A920	o	6.53		
Stylus C92	o	6.53		
Stylus C90	o	6.52		
Stylus D92	o	6.52		
Stylus D92	o	6.52		
Stylus C91	o	6.52		
Stylus C90, Stylus C91, Stylus D92	o	6.52		
Stylus C79	o	6.53		
Stylus D78	o	6.52		
Stylus D78	o	6.52		
Stylus C79	o	6.52		
Stylus C79, Stylus D78	o	6.52		
ME200	o	6.52		Rev.2.9r
Stylus CX2900	o	6.52		
Stylus CX4080	o	6.52		
ME200, Stylus CX2800, Stylus CX2900, Stylus CX4080	o	6.52		
Stylus CX3700, Stylus CX3800	o	6.53		Rev.3.0u
Stylus DX3800	o	5.93		
Stylus CX3700, Stylus DX3800	o	5.93		
Stylus CX5700F, Stylus CX5800F	o	6.53		Rev.3.0zc
Stylus CX5700F	o	6.53		
Stylus CX4100, Stylus CX4200, Stylus CX4700, Stylus CX4800	o	6.53		Rev.3.0u
Stylus DX4200, Stylus DX4800	o	5.93		
Stylus CX4100, Stylus CX4700, Stylus DX4200, Stylus DX4800	o	5.93		
PX-V630	o	6.55		
SC87_SC88_W2K_55bA_MP	w	-		
SD88_W2K_55dDFGIPS_MP	w	-		
SD88_SC87_2k_XP_5.5dExport	w	-		
SC87_SD88_W2K_55dE_MP	w	-		
PictureMate 100	o	5.93		
PictureMate 100	o	5.93		
Stylus Photo R220	o	6.54		
Stylus Photo R230	o	6.53		
SC67_SC68_W2K_55aA_MP	w	-		

SD68_W2K_55b_DFGIPS_FC	w	-		
SC67_SD68_W2K_55bE_MP	w	-		
Stylus Photo R240	o	5.93		
Stylus Photo R240, Stylus Photo R250	o	5.93		
ME PHOTO 20	o	6.52		
ME PHOTO 20	o	6.52		
Stylus Photo RX520	o	5.93		Rev.3.0u
Stylus Photo RX520, Stylus Photo RX530	o	5.93		
Stylus CX7700, Stylus CX7800	o	6.53		Rev.3.0u
Stylus Photo R340, Stylus Photo R350	o	6.53		
STYLUS PHOTO RX640, STYLUS PHOTO RX650	o	6.53		
PictureMate2005_W2K_55bA_MP	w	-		
PictureMate2005_W2K_55bE_MP	w	-		
Stylus Photo R2400	o	6.56		
Stylus Photo R800	o	6.55		
Stylus Photo R1800	o	6.54		
PMG720_W2K_650Js	w	-		
PMD770_W2K_650Js	w	-		
SPR320_W2K_55aA_MP	w	-		
SPR320_55a_DFGIPS_MP	w	-		
SPR320_W2K_55aE_MP	w	-		
SC6768_W2K_55aE_Alpha	w	-		
SPRX620_W2K_55aA_MP	w	-		
SPRX620_W2K_55cDFGIPS_S	w	-		
SPRX6263_W2K_55cES	w	-		
Stylus Photo RX700	o	6.52		Rev.3.0u
Stylus Photo RX700	o	5.93		
Stylus Photo RX700	o	5.93		
PictureMate_W2K_55bAs	w	-		
PictureMate_W2K_55dDFGIPS_S	w	-		
PictureMate_W2K_55dEs	w	-		
PXV600_W2K_592S	w	-		
SC83_84_55aS	w	-		
SC84_W2K_54bE_DFGIPS_MP	w	-		
SC83_84_55aS	w	-		
SC63_64_55aS	w	-		
SC64_W2K_54cE_DFGIPS_MP	w	-		
SC63_64_55aS	w	-		
SC66_W2K_54aE_DFGIPS_MP	w	-		
SC6566_W2K_54aA_MP	w	-		
SC6566_W2K_54aE_MP	w	-		

SC86_W2K_54aE_DFGIPS_MP	w	-		
SC85_86_55bS	w	-		
SC85_86_55aS	w	-		
SPRX600_W2K_55bAs	w	-		
SPRX600_W2K_55aS_DFGIPS	w	-		
SPRX600_W2K_55bEs	w	-		
SPR300_W2K_55bAs	w	-		
SPR300_W2K_55a_DFGIPS_MP	w	-		
SPR300_310_W2K_55bEs	w	-		
SPRX500_W2K_55aS_DFGIPS	w	-		Rev.3.0u
SPRX500_W2K_55bAs	w	-		
SPRX500_510_W2K_55bEs	w	-		
SC46_W2K_55a_DFGIPS_MP	w	-		
SC45_W2K_55aA_MP	w	-		
SC4645_W2K_55aE_MP	w	-		
SC48_W2K_55bDFGIPS_MP	w	-		
SC48_W2K_55bE_MP	w	-		
SPR200_210_55aS_MP	w	-		
SPR200_W2K_54aE_DFGIPS_M P	w	-		
SPR2021_W2K_54aE_MP	w	-		
SCX6300_6400_W2K_55bAs	w	-		
SCX6300_6400_55aS	w	-		
SCX6300_6400_W2K_55bEs	w	-		
SCX5300_5400_55aS	w	-		Rev.3.0u
CX54_W2K_54aE_DFGIPS_MP	w	-		
SCX5354_W2K_54aE_MP	w	-		
SP895EX_53A.MP	w	-		
SP825_915_55aS	w	-		
EPSON Stylus Photo 915	w	-		
SP825_915_55aS	w	-		
EPSON Stylus C42 Series	w	-		
SCX3100_3200_55aS	w	-		
SCX3200.54cDFGIPS.MP	w	-		
SCX3100_3200_55aS	w	-		
SP820_830_55aS	w	-		
SP830_54bDFGIPS.MP	w	-		
SP820_830_55aS	w	-		
SP900_55aS	w	-		
EPSON Stylus Photo 900	w	-		
SP900_55aS	w	-		
PM3700C.53b.MP	w	-		
SC82_55aS	w	-		
SC82_54D_DFGIPS.MP2	w	-		
SC82_55aS	w	-		
SC61_62_55aS	w	-		
SC62_54c_DFGIPS_MP	w	-		
SC6162_54c.MP	w	-		
SP820_W2K_54c_fc3	w	-		
SP830U_W2K_54bDFGIPS_mp	w	-		

SP830U 55aS	w	-		
PM930C 590S	w	-		
PM940C 590S	w	-		
PM860PT_55aS	w	-		
SP935 55aS	w	-		
SCX5100_5200_55aS	w	-		
SCX5200.54bDFGIPS.MP	w	-		
SCX5100 5200 55aS	w	-		
EPSON Stylus C20 Series,EPSON Stylus C40 Series	w	-		
EPSON Stylus C20 Series,EPSON Stylus C40 Series	w	-		
EPSON Stylus C70 Series,EPSON Stylus C80 Series	w	-		
EPSON Stylus C80 Series	w	-		
PM850PT.53c.S	w	-		
EPSON Stylus Photo 925	w	-		
EPSON Stylus Photo 925	w	-		
PM730	w	-		
DFGIPS.SP810c.MP	w	-		
Sp820a MP	w	-		
SP810 55aS	w	-		
PM830C 55aS	w	-		
EPSON Stylus C60 Series	w	-		
SC50 55aS	w	-		

MODEL	Windows10(RS4) In box (Std)	Windows10(RS4) Support Policy (Std Driver)	Windows10(RS4) Support Policy (STM)	Windows10(RS4) Support Policy EPSON UNV Driver
AcuLaser M4000	Epson ESC/Page V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AcuLaser M8000	Epson ESC/Page V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AcuLaser M2300/M2310 M2400/M2410	Epson ESC/Page V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AcuLaser M7000N	Epson ESC/Page V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AL-M300D/DN	Epson ESC/Page V4 Class Driver	Use driver for Windows10	<-Yes	User latest version for Win10
AL-M400DN	Epson ESC/Page V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AL-M200DN/DW	No	TBD	-	TBD
AL-M8200/M8100/M7100	Epson ESC/Page V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AL-M320DN/M310DN/M220DN	Epson ESC/Page V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
EPL-6200L	No*1	MS driver via Internet (Windows Update)		
EPL-2180	No*1	MS driver via Internet (Windows Update)		
AcuLaser M1200	No	Use driver for Vista	<-Yes	
AcuLaser M1400	No	TBD	-	
AcuLaser C9100	No*1	No support Work with MS driver via Internet (Windows Update)	No support	
AcuLaser C2600	No*1	No support Work with MS driver via Internet (Windows Update)	No support	
AcuLaser C4200	No*1	MS driver via Internet (Windows Update)	No support	User latest version for Win10
AcuLaser C3800	Epson Laser ESC/Page-Color	MS driver via Internet (Class driver)	<-Yes	User latest version for Win10
AcuLaser C2800	Epson Laser ESC/Page-Color	MS driver via Internet (Class driver)	<-Yes	User latest version for Win10
AcuLaser C9200	Epson ESC/Page-Color V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AcuLaser C9300N	Epson ESC/Page-Color V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AL-C500DN	Epson ESC/Page-Color V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AcuLaser C3900N	No	TBD	-	User latest version for Win10
AcuLaser C2900N	No	TBD	-	User latest version for Win10
AL-C300	Epson ESC/Page-Color V4 Class Driver	Use driver for Win10	<-Yes	User latest version for Win10
AcuLaser C1100	No*1	MS driver via Internet (Windows Update)	No support	
AcuLaser C1600	No	TBD	-	
AcuLaser C1700	No	TBD	-	
AcuLaser C1750N/W	No	TBD	-	
AL-CX11	Epson ESC/PageS V4 Class Driver	Use driver for Win10 and Using latest Epson Scan is no problem	<-Yes	
AcuLaser CX28DN	No	TBD		
AcuLaser CX16/NF	No	TBD		
AcuLaser CX17/NF/NW	No	TBD	-	
AcuLaser MX14/NF	No	TBD	-	
AcuLaser CX29NF	No	TBD	-	User latest version for Win10
AcuLaser CX37DN/F	No	TBD		User latest version for Win10
AL-MX200DNF/DWF	No	TBD	-	User latest version for Win10

*1 : Not installed at default. But the Vista/7 level inobx driver will appear with "Windows Update".

*4: Vista/7/8 Driver was not released. Use Windows 2000 or XP driver for 32bit. For 64bit, use XP64 driver (TE05-0191B)

TBD: Not fully supported at the moment

About PCL Universal Driver:

SEC will support only P6 UNV driver after Windows 8.

The old model which is not supported by P6 UNV driver, the current P6 generic driver or P5C driver may be work with some restrictins. But SEC end the maintenance of these old drivers.

Product Name	Win10(1607) Support	
	x32 Edition Support	x64 Edition Support
GT-9300	o	o
Perfection 2400	o	o
GT-9800	o	x
Perfection 3200	o	x
GT-7400	o	o
Perfection 1270	o	o
GT-8400	o	x
Perfection 1670	o	x
GT-9400	o	o
Perfection 3170	o	o
GT-X700	o	o
Perfection 4870	o	o
GT-F670	o	o
Perfection V200	o	o
GT-S620/F720	o	o
Perfection V30/V300	o	o
GT-S640/F740	o	o
Perfection V37/V370	o	o
Perfection V550	o	o
Perfection V800 Photo	o	o
Perfection V19	o	o
GT-S650	o	o
Perfection V39	o	o
GT-9600	o	x
Expression 800	o	x
GT-9600	o	o
ES-9000H	o	o
GT-30000	o	o
GT-D1000	o	o
GT-15000	o	o
GT-S55	o	o
GT-S85	o	o
DS-30	o	o
DS-30	o	o
DS-30	o	o
DS-5500/6500/7500	o	o
DS-50000/60000/70000	o	o
DS-510	o	o
DS-560	o	o
DS-860	o	o
DS-760/860	o	o
DS-40	o	o
DS-40	o	o
DS-520	o	o
DS-530	o	o
DS-535	o	o
DS-530	o	o
DS-570W	o	o
DS-575W	o	o
DS-1630	o	o
DS-1610	o	o
DS-1660W	o	o
DS-310	o	o
ES-200	o	o
DS-320	o	o
DS-360W	o	o
DS-770	o	o
DS-775	o	o
DS-780N	o	o
DS-410	o	o

	CD / Web 32bit Win10(1803)	CD / Web 64bit Win10(1803)	Windows Update Win10(1803)
LX-300+II	○	○	○
LX-310/350	○	○	×
LX-1310/1350	○	○	×
LX-1170II	○	○	○
FX-890	○	○	○
FX-890A			
DFX-9000	○	○	○
LQ-300+II	○	○	○
LQ-310/350	○	○	×
LQ-1310	○	○	×
LQ-590	○	○	○
LQ-2090	○	○	○
LQ-680Pro	○	○	○
LQ-690	○	○	×
LQ-1150II	○	○	○
LQ-2180	×	×	×
LQ-2190	○	○	×
DLQ-3500	○	○	○
PLQ-20	○	○	×
PLQ-20M			
PLQ-20D	○	○	×
PLQ-20DM			
PLQ-22CS	○	○	×
PLQ-22CSM			
PLQ-22	○	○	×
PLQ-22M			
PLQ-30	○	○	×
PLQ-30M			
LQ-590II	○	○	×
LQ-590IIN	○	○	×